


■ INSTALLATION SCHEMES

DEVICES INSTALLED IN A HAZARDOUS AREA

A BXF Coupler must be used at either end of the Ethernet cable to ensure the safety of this system.

The BXF must be securely mounted and grounded within a UL/CSA (or equivalent), MSHA or ATEX/IECEx approved explosion proof enclosure.



DEVICES INSTALLED IN BOTH AN HAZARDOUS AND A SAFE AREA

One BAF and one BXF Coupler must be used at opposite ends of the Ethernet cable to ensure the safety of this system.

The BXF must be securely mounted and grounded within a UL/CSA (or equivalent), MSHA or ATEX/IECEx approved explosion proof enclosure.

