




Selection chart Accessories for Barcode Hand-held scanner BCS 160^{ex}

Illustration	Description	➔ Order no.
	<p>Connection cable</p> <ul style="list-style-type: none"> ■ RJ45 to BCS 160^{ex} Barcode Hand-held scanner ■ assembled with 4 pin plug to power pack <ul style="list-style-type: none"> - Scanner cable, RS232, plane, 1.8 m - Scanner cable, RS232, spiral, 3.8 m - Scanner cable, USB, plane, 1.8 m - Scanner cable, USB, spiral, 3.8 m 	<p>03-9828-0034 03-9828-0035 03-9828-0036 03-9828-0037</p>
	<p>Extension cable (plane)</p> <ul style="list-style-type: none"> ■ 6.0 m ■ assembled with plug/coupling 	<p>03-9828-0038</p>
	<p>Extension cable (spirale cable)</p> <ul style="list-style-type: none"> ■ 4.5 m ■ assembled with plug/coupling 	<p>03-9828-0039</p>
	<p>Connection cable to following systems:</p> <ul style="list-style-type: none"> ■ POLARIS power modul ■ Power pack of BCS 302^{ex} Type 17-21BB-0217 bis 17-21BB-0220 ■ Power pack of BCS 3800^{ex} Type 17-21BB-1700 bis 17-21BB-1702 ■ RJ45 to BCS 160^{ex} hand-held scanner ■ assembled with 4 pin plug to power pack <ul style="list-style-type: none"> - Scanner cable, RS232, plane, 1.8 m - Scanner cable, RS232, spiral, 3.8 m 	<p>17-21BE-M000/0000 17-21BE-M010/0000</p>
	<p>Desk holder</p>	<p>03-9849-0065</p>
	<p>Tripod holder</p>	<p>03-9849-0066</p>